

Instructions:

Kodak N2040/N2050 Series Scanners

Stacking Deflector Accessory

Translation of these instructions is available at the on-line support page for your scanner model, for instance:

توجد ترجمة لهذه التعليمات على صفحة الدعم المتوفرة عبر الإنترنت والتي تناسب طراز الماسحة الضوئية، على سبيل المثال:

这些说明的译文请参阅扫描仪型号的在线支持网页，例如：

如需這些說明的翻譯，請參見您掃描器型號的線上支援，例如：

La traduction de ces instructions est disponibles sur la page de support en ligne pour votre modèle de scanner, par exemple :

Eine Übersetzung dieser Anweisungen ist auf der Online-Supportseite zu Ihrem Scannermodell verfügbar, wie zum Beispiel:

Una traduzione di queste istruzioni è disponibile presso la nostra pagina di assistenza online per i modelli di scanner:

これらの手順の翻訳は、ご使用のスキャナーモデルごとにオンラインサポートページからご利用になれます。例：

해당 스캐너 모델의 온라인 지원에서 이 지침의 번역 내용을 확인할 수 있습니다. 예：

A tradução dessas instruções está disponível na página de suporte on-line para o seu modelo de scanner, por exemplo:

Перевод настоящего руководства доступен на странице онлайн-поддержки для вашей модели сканера, например:


La traducción de estas instrucciones está disponible en la página de asistencia en línea específica para su modelo de escáner, por ejemplo:

Bu talimatların çevirilerine tarayıcınızın modelinin çevrimiçi destek sayfasından ulaşabilirsiniz, örneğin:

www.KodakAlaris.com/go/N2000support

Contents of the kit:

This kit contains:




- One Stacking Deflector Accessory.

Expected use of stacking deflector

The stacking deflector accessory attaches to the front lower edge of the scanner cover. It helps paper exiting the scanner to remain in order and to stack correctly.


How to install

1. Turn the locking knob to vertical.




2. Hold the stacking deflector slightly in front of and lower than the front lower edge of the scanner cover, with the leg pointing away from the scanner.

3. The deflector bracket has four tabs. These tabs need to line up with four slots in the lower edge of the scanner cover.
4. When the tabs are lined up, squeeze on the small touch points to left and right of the locking knob. Squeeze, and then push the four tabs into the slots. Stop squeezing once the stacking deflector is seated against the lower edge of the scanner cover.



5. Turn the locking knob horizontal into its locked position. The stacking deflector is now held in place on the scanner. When the deflector is




installed correctly, they will touch the partially extended output tray.


How to use

Scanning paper of mixed lengths

1. The stacking deflector leg is down for use.
2. The leg length is adjustable. Hold the stacking deflector at the touch points on the central hub when you want to change their length.




3. When scanning pages of different lengths (such as a form accompanied by a check), adjust the stacking deflector accessory leg so they will trap the shorter page. The longer pages will push under the deflector leg, but shorter pages will stay close to the scanner.



4. If scanning pages of several different lengths (for example 3 inches, 5 inches, and 11 inches long), adjust the deflector legs so they will trap all the shorter pages. In this example, adjust to trap the 5 inch pages. The shorter pages will stay near the scanner, and the longer pages will push beyond the stacking deflector leg.

Normal jobs

If your jobs stack nicely without the stacking deflector accessory, you can flip it up so the stacking deflector rests on the scanner cover.



Flip the stacking deflector down again when needed. The stacking deflector is *not* recommended for lightweight pages longer than 150 mm (5.9 inches).

